S-V10 3IN1-V2-20220424 【七国语言】
装订成品尺寸： 112mm*165mm
材质： 100g 书写纸
装订方式： 装订版 总共页数： 页
印刷：双色 橙色 ■ PANTONG 151C 黑色 ■

PXN V10 3IN1



User Manual

产品说明书

ENGLISH / 简体中文

Thank you for choosing PXN products and your support for our brand. please read this manual carefully before starting to enjoy your gaming experience.
感谢您选择PXN来完成产品，感谢您对PXN来完成品牌的支持，在使用之前请仔细阅读本手册。

APPEARANCE / 产品外观



PRODUCT CONTENT / 配件图



SYSTEM REQUIREMENTS / 系统要求

Supported platforms : PC / PS4 / X-ONE / X-Series X|S
Supported operating systems : Windows 7 / 8 / 10 / 11
Note: Original controller should be used for guidance while playing on PS4 and X-ONE / X-Series X|S platforms.
支持平台：PC / PS4 / X-ONE / X-Series X|S
PC 电脑系统要求：Windows 7 / 8 / 10 / 11
注：PS4 和 X-ONE / X-Series X|S 平台游戏需要原装手柄进行引导

BACK INTERFACE OF THE STEERING WHEEL / 方向盘背面接口

Back Interface Connection Diagram
【 背面接口连接示意图 】



STEERING WHEEL INSTALLATION INSTRUCTION / 方向盘安装方法

- Assembling of Panel and Base / **组装盘面与基座**

Step 1 Align the panel with the panel mounting position of the base, hold the steering wheel dial, and tighten the locking ring.

Step 1 将盘面对准基座的盘面安装位，握住方向盘刻，并紧紧锁圈。



- Steering Wheel Fixed Instruction / **固定方向盘**

Step 1 Use an Allen key to remove the screws at the position and install the clamp.
Step 2 Use the Allen key tightened the screw of the clamp to lock the clamp.

Step 1 拆开选择盘面螺丝的位置，并安装夹具。
Step 2 使用内六角扳手拧紧夹具上的螺丝，锁紧夹具。



- Steering Wheel Tilt Adjustment Instruction / **方向盘倾角调节**

When in use, you can set the inclination of the steering wheel base with 4 gears.
Step 1 Use an Allen key to remove the screws shown in the figure.
Step 2 Adjust the inclination of the base to the corresponding hole position and tighten the screws.

使用时可设置方向盘基座倾角，共 4 档。
Step 1 使用内六角扳手拆下图示螺丝。
Step 2 调整基座倾角到对应的孔位，锁紧螺丝。



FOOT PEDALS INSTALLATION INSTRUCTION / 脚踏板安装方法

- Panel Angle Adjustment of Foot Pedal / **脚踏板角度调节**

Step 1 Use an Allen key to loosen and remove the 2 Allen screws.
Step 2 Adjust the pedal to the desired angle, install and tighten the 2 Allen screws.

Step 1 使用内六角扳手松开并拆下 2 颗内六角螺丝。
Step 2 调整踏板到所需角度，装上并拧紧 2 颗内六角螺丝。

- Pedal Strength Adjustment Instruction / **脚踏力度调节**

Step 1 Rotate the parts shown in the figure to adjust the pedal strength.

Step 1 旋转图示部件即可调节踏板力度。

Note: Please adjust the parts within the thread range.
注意：请在螺纹范围内调节部件。



- Foot Pedal Fixed Instruction / **脚踏板固定**

Step 1 There are 4 screw holes reserved at the bottom of the foot pedal to fix the pedal to the bracket by combining the corresponding screws.

Step 1 踏板底部留有 4 个螺丝孔，可使用相配螺丝固定在支架上。



INSTRUCTION FOR PLAYING ON PC / PC 电脑使用

Step 1 Connect the gear shift and foot pedals to the steering wheel.
Step 2 Fix the steering wheel and connect it to the power adapter.
Step 3 Plug the USB main cable of the steering wheel to the PC.
Step 4 The steering wheel will be in D-input mode by default if successfully connected, and the red indicator on the steering wheel will be always on.

- Mode Switch While Playing on PC

The steering wheel is in D-input mode by default. Press the "PS" button for 3 seconds to switch to X-input mode and a purple indicator will be always on if successfully switched.
Mode Switch by "PS" Button

D - Input ←——— Press the "PS" button for 3 seconds ———→ X - Input

D-input mode supports force feedback function (requires the game to support force feedback)
Recommended games: Euro Truck Simulator 2, Forza Horizon 5, Assetto Corsa: Racing, Dirt Rally 2.0, F1 2020.
No forcefeedback feedback function in X-input mode
Recommended games: Forza Horizon 4 (Steam version), Spintires: Snowrunner, Need for Speed: Heat Pursuit

PC 电脑使用

Step 1 首先将换挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并连接电源适配器。
Step 3 将方向盘 USB 主线插入 PC 电脑。
Step 4 连接成功默认为 D-input 模式，方向盘上红色指示灯长亮。

- **PC 模式切换**

方向盘默认为 D-input 模式，长按 " PS " 键 3 秒可切换至 X-input 模式，切换成功后方向盘上紫色指示灯长亮。
" PS " 键切换模式方法：

D - Input ←——— 长按 " PS " 键 3 秒 ———→ X - Input

D-input 模式支持力反馈功能（需游戏支持力反馈）
推荐游戏：欧洲卡车模拟 2，极限竞速：地平线 5，神力科恩：赛道，尘埃拉力赛 2.0，F1 2020。
X-input 模式无力反馈
推荐游戏：极限竞速：地平线 4（Steam 版本），斯科特雪地：雪地救援，极品飞车：热力追逐。

INSTRUCTION FOR PLAYING ON PS4 / PS4 主机使用

Step 1 Connect the gear shift and foot pedals to the steering wheel.
Step 2 Securely install the steering wheel and connect to the power adapter.
Step 3 Turn off the PS4 original controller and use the USB data cable to connect the controller to the controller interface of the steering wheel.
Step 4 Plug the USB main cable of the steering wheel into the USB port of the PS4 host.
Step 5 Turn on the PS4 host.
Step 6 Press the "PS" button of the steering wheel and the blue indicator of the steering wheel will be always on if connected successfully.

Step 1 首先将换挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并连接电源适配器。
Step 3 关闭 PS4 原装手柄，使用 USB 数据线将 X-ONE / X-Series X|S 原装手柄连接至方向盘手柄接口。
Step 4 将方向盘 USB 主线插入 PS4 主机的 USB 接口。
Step 5 开启 PS4 主机电源。
Step 6 连接成功后方向盘手柄上的 " PS " 键，连接成功后方向盘蓝色指示灯长亮。

INSTRUCTION FOR PLAYING ON X-ONE/ X-SERIES X|S / X-ONE/ X-SERIES X|S 主机使用

Step 1 Connect the gear shift and foot pedal to the steering wheel.
Step 2 Fix the steering wheel and connect it to the power adapter.
Step 3 Turn off the X-ONE / X-Series X|S original controller and use the USB data cable to connect the controller to the controller interface of the steering wheel.
Step 4 Plug the steering wheel USB main cable into the USB port of the X-ONE / X-Series X|S host and turn on the X-ONE / X-Series X|S.
Step 5 Press the "PS" button of the steering wheel and the green indicator will be always on.

Step 1 首先将换挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并连入电源适配器中。
Step 3 关闭 X-ONE / X-Series X|S 原装手柄并连接，使用 USB 数据线将 X-ONE / X-Series X|S 原装手柄连接至方向盘手柄接口。
Step 4 将方向盘 USB 主线插入 X-ONE / X-Series X|S 主机 USB 接口，打开 X-ONE / X-Series X|S 主机电源。
Step 5 按下方向盘 " PS " 键，连接成功后方向盘绿色指示灯长亮。

STEERING WHEEL ADVANCED SETTINGS / 方向盘高阶设置

Download the PXN Wheel APP on your mobile phone to get the advanced settings of the steering wheel:
Main Functions of the APP:

- Steering wheel rotation degree setting
- Force feedback setting
- Button mapping setting
- Game preset button configuration
- Steering wheel button map

Scan the QR code to download the APP

在手机端下载【PXN 方向盘】APP 可实现更为高级高阶设置。
APP 主要功能说明：

- 方向盘转向角角度设置
- 方向盘力反馈设置开关
- 按键映射设置功能
- 游戏预设键位设置
- 方向盘按键映射

扫描下载 APP 及查看教程

PRECAUTIONS / 注意事项

- Please read the manual carefully before using.
- Avoid strong vibration and gravity drop.
- Do not disassemble the product by yourself.
- Prevent water or other liquids from getting into the product to avoid damage.
- Avoid storing products in some places with humid, high temperature,oily smoke, etc.
- Please pay attention when connecting and removing devices to avoid damage.
- Children can only use the product under the supervision of an adult.

- 请先阅读说明书再使用。
- 避免强烈振动及重力跌落。
- 请勿自行拆解产品。
- 避免水或其它液体进入产品内部，以免造成损坏。
- 避免在潮湿、高温、油烟等场所。
- 连接和拆卸设备时请注意。
- 儿童需在成年人的监护下使用本产品。

PRODUCT SPECIFICATIONS / 产品规格

Product Model	PXN - V10 (3in1)	产品型号	PXN - V10 (3in1)
Connection Method	USB Wired	连接方式	USB 有线
Working Voltage	Motor Working Power: DC24 V; USB Working Power: 5 V	工作电压	电机工作电源：DC24 V USB工作电源：5 V
Working Current	Motor Working Current: 2A USB Working Current: ≤ 500mA (Use the original original controller for guidance)	工作电流	电机工作电流：2A USB工作电流：引导时 ≤ 500mA
Package Size	About 406 * 355 * 370 mm	包装尺寸	约 406 * 355 * 370 mm
Product Size	About 270 * 280 * 249 mm (3 Foot pedals) About 410 * 340 * 220 mm (2 Foot pedals) About 180 * 155 * 200 mm (Gear shift)	各块尺寸	约 270 * 280 * 249 mm（三件踏板） 约 410 * 340 * 220 mm（二脚踏板） 约 180 * 155 * 200 mm（换挡杆）
Product Weight	About 2949 g (Steering wheel) About 3180 g (3 Foot pedals) About 577g (Gear shift)	各块重量	约 2949 克（方向盘） 约 3180 克（三脚踏板） 约 577 克（换挡杆）
Operating Temperature	10-40 °C	使用温度	10-40 °C
Operating Humidity	20 – 80 %	使用湿度	20—80 %