




PD HM



RACING PEDAL

USER MANUAL

Please read the manual carefully before using the product, and keep this manual for future reference.

⚠ Warning — Safety

- * Please connect, install and remove this product with proper force, don't twist or pull the connectors and cables.
- * Avoid getting water or other liquids on product or its connectors.
- * Please don't disassemble, refit or repair on your own. Any repairs must be carried out by the manufacturer, its authorized representatives or qualified technicians.
- * Please use the attached system/accessories specified by manufacturer only.

⚠ Warning — Pedal set pinch hazard when playing

- * Keep the pedal set out of children's reach.
- * During gameplay, never place your fingers on or anywhere near the sides of the pedals.
- * During gameplay, never place your fingers on or anywhere near the pedal's rear base.
- * During gameplay, never place your fingers on or anywhere near the pedal's front base.



NEVER



NEVER



NEVER

⚠ Automatic Calibration of the Pedals

After connecting successfully, the pedals will automatically calibrate when you press each pedal to its maximum travel distance.

⚠ Warning

Never press the pedals during the racing wheel's self-calibration or while a game is loading.

For safety reasons, never use the pedal set with bare feet or while wearing only socks on your feet.
PXN® is not responsible for injuries caused by using pedals without shoes on.

The product can only be operated by users aged 16 or above.


System Requirement

Supported racing wheel: PXN-V10, V12 DDL, V12 DDS

Supported platform: PC

System requirement on PC: Windows 7 / 8 / 10 / 11

Package Content



Installation


• Clamp the Pedals

The pedal can be installed on a bracket or a racing seat.

Step 1 Align the screw holes at the bottom of the pedal with the installation holes.

Step 2 Secure the pedal with screws and nuts.

Step 3 Tighten the screws and nuts with an Allen key and a wrench.



• Pedal Assembly



The pedal can be attached to a bracket or a racing seat.

Step 1 Take out the pedal set and pedal board.


Step 2 Connect the clutch and accelerator to the brake pedasl using a RJ cable.

Step 3 Fasten three pedal sets on the pedal board using included KM4*10mm Hex bolts and M4 Allen key.

Pedal Assembly STEP 1:



Pedal Assembly STEP 2:




Connect with PC

Step 1 Secure the pedal in the appropriate position.

Step 2 Connect the pedal to the PC using a USB-B cable.

Step 3 After successful connection, press each pedal to its maximum travel distance for calibration before use.




Connect with PXN Wheel Base

Step 1 Secure the pedal in the appropriate position.

Step 2 Connect the pedal to the PXN Wheel Base using a RJ cable.

Step 3 After successful connection, press each pedal to its maximum travel distance for calibration before use.



Advanced Pedal Settings

Download APP on iOS: Search for [PXN Wheel] in the App Store.

Download for Android: Search [PXN Play] in Google Play.

Connect the pedals with PXN Wheel Base and download the [PXN Wheel] APP on the mobile phone to explore advanced pedal settings.

The main functions of the APP are:

- Real-time data viewing of the pedal
- Pedal linearity adjustment
- More functions are under development

Attentions

- Avoid strong vibration, do not disassemble, modify or repair by yourself.
- Prevent water or other liquids from entering the product to avoid damage.
- Avoid storing in humid, high temperature, oily smoke and other places.
- Please do not throw the product into fire to avoid explosion.
- Children should be under adult's supervision at all times when using this product.
- If you have any problems or suggestions about the product, please contact the seller or the after-services.

Product Specifications

Model	PD HM
Connection Method	Wireless Connection
Working Power	Working Power of USB: 5V
Working Current	Working Current of USB: 85 mA
Package Size	About 520 * 375 * 136 mm
Product Size	About 350 * 315 * 225 mm
Product Weight	About 3890 g
Use Temperature	10-40 °C
Use Humidity	20~80 %